

# **Quick Guide**

### **D-LITE RX ONE** D-LiTE RX 2/4 BRX 250/500

**Programming** 

#### **Function**

Power	<b>(</b> )	Down / Up
Ready charge beep		On / Off
Test		Manual trigger
Photocell		On / Off
Eye cell pre-flash sensor	Press 4s	On
Modelling lamp		Free/Prop
Master reset	Press together (	and turn on the unit

#### **El-Skyport Transmitter Speed**



RX feature button Power decrease

RX feature button Power increase or modelling lamp

Flash Test / Flash Mode / Configuration button

## **Frequency Channel**





The NORMAL and SPEED SYNC Mode is also available with D-Lite it 2/4 and BXRi 250/500.

**Speed Sync Function Setup** Synchronises D-SLR cameras up to 1/250 s

**Normal Sync Function Setup** 

Synchronises D-SLR cameras up to 1/160 s

Toggle mode

5s

flashes two times. Press

flashes one time. -)0(-

Status LED

Speed mode

on the flash unit display



Normal mode



Master reset

Press 10s



## **Quick Guide**

#### Enter Toggle Setting **Programming** into sub-menu menu On Set with Visual flash control Press Set Modelling Lamp to turn off during recharge $\blacksquare$ 2s Off (١ Set with On Proportional modelling lamp set up Set Modelling Lamp to 50% on 250ws Head for proportionality with 500ws Head Off Press Set with Charge ready beep set-up 2s Set ready beep between 70-490 ms Between 70-490 ms A Auto count the flash Red eye pre-flash recognition Press Set with No pre-flash 4s 6 pre-flash **EL-Skyport activation** Off Set with Normal mode Speed mode **EL-Skyport group settings** Press Set with together Group 1 to 4 **EL-Skyport frequency channel** Set with settings Channel 1 to 8 Power & modelling steps set-up 1 stop Set power change to steps 1/10, 5/10 or up to 1/1 f-stop 1/10 5/10 and turn on again Master reset Switch off the unit than press together (▼